

K-58 ASSEMBLY INSTRUCTIONS

PART LIST	
1-RING	
1-RING BOLT	
1-UP MAST	
1-DOWN MAST	
1-BASE	
1-BASE BOLT	
BOLTS ARE SCREWED IN PLACE	

